# CSE 232 Section B, Computer Networks; Programming Assignment 1: UDP Pinger Lab

nment 1: UDP Pinger Lab

Harsh Rajput (2022201) Aryan Singla (2022112)

### Part 1: **UDP Ping Client System**

This system simulates the functionality of the common network utility tool *Ping* using the User Datagram Protocol (UDP). The primary purpose is to send a series of "ping" messages to a server, measure the round-trip time (RTT) for each response, and calculate statistics such as minimum RTT, maximum RTT, average RTT, and packet loss rate. The client sends 10 ping requests and waits for a response from the server.

## Server code

```
D ~ [] ...
UDPPingerServer.py ×
UDPPingerServer.py > ...
       # We will need the following module to generate randomized lost packets
       import time
       import random
       from socket import *
       serverName = "localhost"
       serverPort = 12000
       serverAddress = (serverName, serverPort)
       # Create a UDP socket
      # Notice the use of SOCK DGRAM for UDP packets
       serverSocket = socket(AF_INET, SOCK_DGRAM)
       # Assign IP address and port number to socket
       serverSocket.bind(('', serverPort))
       while True:
           # Generate random number in the range of 0 to 10
          rand = random.randint(0, 10)
          # Receive the client packet along with the address it is coming from
          message, clientAddress = serverSocket.recvfrom(1024)
          # Capitalize the message from the client
          modifiedMessage = message.decode('utf-8').upper().encode('utf-8')
          # If rand is less is than 4, we consider the packet lost and do not respond
          if rand < 4:
           # Otherwise, the server responds
          serverSocket.sendto(modifiedMessage, clientAddress)
 25
```


## Client code

```
▷ ∨ Ⅲ …
UDPPingerClient.py
UDPPingerClient.py > ...
       import time
       from socket import *
       serverName = "localhost"
       serverPort = 12000
       serverAddress = (serverName, serverPort)
      TIME OUT = -1
      serverResponses = []
      clientSocket = socket(AF INET, SOCK DGRAM) # Notice the use of SOCK DGRAM for UDP packets
      clientSocket.settimeout(1)
      print(f"PING {serverName} 10 times")
      total_ping = 10
      for sequence number in range(1,total ping+1):
           time sent = time.time()
           message = f"Ping {sequence number} {time.ctime(time sent)}".encode('utf-8')
           clientSocket.sendto(message,serverAddress)
           # Wait for the server to respond
              modifiedMessage, serverAddress = clientSocket.recvfrom(1024)
              modifiedMessage = modifiedMessage.decode('utf-8')
              time received = time.time()
              rtt = (time received - time sent)*1000
              print(f"udp_seq={sequence_number} message=\"{modifiedMessage}\" rtt={rtt:.3f}ms")
              serverResponses.append(rtt)
           except timeout:
              print(f"udp_seq={sequence_number} Request timed out ")
              serverResponses.append(TIME_OUT)
       clientSocket.close()
```

#### Code to calculate metrics

```
D ~ III ...
UDPPingerClient.py
UDPPingerClient.py > ...
      # Report the minimum RTT, maximum RTT, average RTT, and packet loss rate at the end of all pings from the client
      total time = 0
      packet_loss = 0
      rtt_min = float('inf')
      rtt max = float('-inf')
      for rtt in serverResponses:
          if rtt == TIME OUT:
               packet loss += 1
              total_time += rtt
              rtt min = min(rtt min,rtt)
              rtt max = max(rtt max,rtt)
      packet transmitted = len(serverResponses)
      packet received = packet transmitted - packet loss
      packet_loss_rate = (packet_loss/packet_transmitted)*100
      if packet received == 0:
          rtt avg = 0
          rtt avg = total time/packet received
      print(f"\n--- {serverName} ping statistics ---")
      print(f"{packet_transmitted} packets transmitted, {packet_received} received, {packet_loss_rate:.2f}% packet loss")
      print(f"rtt min/avg/max = {rtt_min:.3f}/{rtt_avg:.3f}/{rtt_max:.3f} ms")
```

#### Client end output



#### Part 1: UDP Heartbeat Client and Server System

Another similar application to the UDP Ping would be the UDP Heartbeat. The Heartbeat can be used to check if an application server is up and running or not. The client sends a sequence number and current timestamp in the UDP packet to the server, which is listening for the Heartbeat (i.e., the UDP packets) from the client. Upon receiving the packets, the server calculates the time difference and reports it back. If the server response to client Heartbeat packets is missing for some specified number of times (say 3), the client can assume that the server application has stopped. Here again simulate a UDP packet loss at rate 30%.

## Server code

```
D ~ [] ...
UDPHeartbeatServer.py X
UDPHeartbeatServer.py > ...
      # We will need the following module to generate randomized lost packets
      import time
      import random
      from socket import *
      serverName = "localhost"
      serverPort = 12000
      serverAddress = (serverName, serverPort)
      # Create a UDP socket
      # Notice the use of SOCK DGRAM for UDP packets
      serverSocket = socket(AF_INET, SOCK_DGRAM)
      serverSocket.bind(('', serverPort))
      while True:
          rand = random.randint(0, 10)
          # Receive the client packet along with the address it is coming from
          message, clientAddress = serverSocket.recvfrom(1024)
          time received = time.time()
          message = message.decode('utf-8').split()
          sequence number = int(message[1])
          time_sent = float(message[2])
          time_difference = (time_received - time_sent)*1000
          modifiedMessage = f"Ping {sequence number} time difference={time difference:.3f}ms".encode('utf-8')
          if rand < 4:
          serverSocket.sendto(modifiedMessage, clientAddress)
```

## Client code

```
▷ ∨ □ …
UDPHeartbeatClient.py
 UDPHeartbeatClient.py > ...
       import time
       from socket import *
       serverName = "localhost"
       serverPort = 12000
       serverAddress = (serverName, serverPort)
       TIME OUT = -1
       serverResponses = []
       clientSocket = socket(AF_INET, SOCK_DGRAM) # Notice the use of SOCK_DGRAM for UDP packets
       clientSocket.settimeout(1)
       Heartbeat = 3
       print(f"PING {serverName} 10 times")
       total ping = 10
       for sequence number in range(1,total ping+1):
          time sent = time.time()
          message = f"Ping {sequence number} {time sent}".encode('utf-8')
          clientSocket.sendto(message,serverAddress)
              modifiedMessage, serverAddress = clientSocket.recvfrom(1024)
              modifiedMessage = modifiedMessage.decode('utf-8')
              time received - time.time()
               rtt = (time received - time sent)*1000
               print(f"udp seq={sequence number} message=\"{modifiedMessage}\" rtt={rtt:.3f}ms")
              serverResponses.append(rtt)
              Heartbeat = 3
           except timeout:
              print(f"udp seq={sequence number} Request timed out ")
              serverResponses.append(TIME_OUT)
              Heartbeat -= 1
              if (Heartbeat == 0):
                  print("Server is down")
       clientSocket.close()
```

#### Client end Output

```
区Code + ~ 日 前 ··· 〈 ×
PROBLEMS
         OUTPUT DEBUG CONSOLE TERMINAL
                                                   SOLCONSOLE COMMENTS
PS F:\CN\A1> python "f:\CN\A1\UDPHeartbeatClient.py"
PING localhost 10 times
udp_seq=1 message="Ping 1 time difference=4.649ms" rtt=5.644ms
udp seq=2 Request timed out
udp seq=3 message="Ping 3 time difference=0.000ms" rtt=0.000ms
udp seq=4 message="Ping 4 time difference=0.000ms" rtt=0.993ms
udp seg=5 Request timed out
udp_seq=6 message="Ping 6 time difference=0.000ms" rtt=0.000ms
udp seq=7 Request timed out
udp_seq=8 message="Ping 8 time difference=0.000ms" rtt=0.000ms
udp seq=9 message="Ping 9 time difference=0.000ms" rtt=0.000ms
udp sea=10 Request timed out
--- localhost ping statistics ---
10 packets transmitted, 6 received, 40.0% packet loss
rtt min/avg/max = 0.000/1.106/5.644 ms
PS F:\CN\A1> python "f:\CN\A1\UDPHeartbeatClient.py"
PING localhost 10 times
udp seq=1 Request timed out
udp seq=2 message="Ping 2 time difference=1.049ms" rtt=1.049ms
udp_seq=3 message="Ping 3 time difference=0.000ms" rtt=0.000ms
udp seg=4 message="Ping 4 time difference=0.000ms" rtt=0.000ms
udp seq=5 message="Ping 5 time difference=0.000ms" rtt=0.000ms
udp seg=6 message="Ping 6 time difference=0.000ms" rtt=0.000ms
udp_seq=7 Request timed out
udp seq=8 Request timed out
udp seq=9 Request timed out
Server is down
--- localhost ping statistics ---
9 packets transmitted, 5 received, 44.44444444444 packet loss
rtt min/avg/max = 0.000/0.210/1.049 ms
PS F:\CN\A1>
```